

Expandable Stick Meters



HS36

HS33, HS35, HS36 The Perfect Fit for Most HVACR Jobs

The HS30 Series meters are some of the most versatile HVACR meters around. Already packed with the measurements HVACR pros need, they also connect directly into Fieldpiece Accessory Heads, so techs don't need extra meters for additional measurements.

- Ruggedized rubber corners
- Magnetic strap for hands-free testing
- High voltage indicators
- Lead storage
- Non-contact voltage
- Capacitance
- MIN/MAX and Hold buttons to record measurements
- Low ohms for motor windings
- Fast, accurate temps



HS33

HS35

Included

- 400A AC amp clamp accessory – ACH4
- Type K thermocouple – ATB1
- Deluxe silicone test leads – ADLS2
- Alligator clip lead extensions – ASA2
- 4-Pocket meter case – ANC1
- Velcro strap



HS33	HS35	HS36	Function	Range	Resolution
Manual	Auto	Auto	Ranging		
2000	4000	4000	Counts		
Average	Average	True RMS	AC Conversion		
		●	Backlight		
		●	Bar Graph		
	●	●	VAC	200m	1.2% + 5/0.1m
	●	●		2000m	1.5% + 5/1m
	●	●		40	1.5% + 5/0.01
●	●	●		200	1.5% + 5/0.1m
●	●	●		600	2% + 5/1
●	●	●	VDC	200m	0.5% + 2/0.1 m
●	●	●		2000m	0.5% + 2/1m
	●	●		20	0.5% + 2/0.01
●	●	●		200	0.5% + 2/0.1
	●	●		600	0.5% + 2/1
●	●	●	AAC	20	2.7% + 7/0.1
●	●	●		100	3.7% + 8/0.1
●	●	●		400	5.0% + 10/1
	●	●	ADC	400μ	1% + 2/0.1 μ
	●	●		4000μ	1% + 2/1 μ
●	●	●	°F	200° F	1° F/0.1
	●	●		1000° F	1° F/1
●	●	●	MFD	200	3% + 5/0.1m
●	●	●	Hi-V Indicator		>30V
●	●	●	NCV		>24VAC
●	●	●	Ohms	200	1% + 4/0/1
	●	●		4K	1% + 4/1
	●	●		40K	1% + 4/10
●	●	●		200K	1% + 4/100
	●	●		4M	1.5% + 4/1K
	●	●		20M	3% + 5/10K
●	●	●	Continuity		
●	●	●	Diode		
	●	●	HZ		

● With ACH4 clamp head, ● LED and beeper, ● Range is 40XX, not 20XX
Temperature accuracies shown are after simple field calibration

