

Instructions

TO CONNECT FITTING:

1. Cut the Tube.
2. De-burr.
3. Use prep tool (sold separately), refer to chart to determine depth.
4. Mark insertion depth.
5. Push into fitting until grip ring securely clamps.
6. Gently pull on the tube to ensure proper seating.

Product Size	Insertion Depth	Recommended Torque Specifications
1/4" Fitting	1"	14 – 18 ft-lbs
3/8" Fitting	1-1/4"	24 – 30 ft-lbs
1/2" Fitting	1-1/4"	40 – 47 ft-lbs
5/8" Fitting	1-5/16"	46 – 59 ft-lbs
3/4" Fitting	1-1/2"	–
7/8" Fitting	1-9/16"	–

TO DISCONNECT FITTING:

The refrigeration system must be isolated, or pumped down before disconnecting. Press the release with disconnect clip to remove tubing. Make sure that the fitting and tube are free from defects. The fitting and tubing should be free of damage, foreign object and marks on the outside diameter. Do not insert fingers in the grip ring inside the fitting.

⚠ WARNING This product can expose you to chemicals including Lead, which is known to the State of California to cause cancer, birth defects or other reproductive harm. For more information, go to www.P65Warnings.ca.gov.

For additional technical information, call toll free 1-800-231-3345.

Limited Warranty



For more information on our product limited warranty, visit RectorSeal.com

Distributed by

RectorSeal, LLC

2601 Spenwick Drive, Houston, TX 77055, USA • 800-231-3345 • Fax 800-441-0051 • rectorseal.com

Australia Pty Ltd. • PO Box 5266 Brendale, Qld 4500 • 1300 77 2878 • rectorseal.com.au

3255 Wyandotte St. East • Windsor, ON N8Y 1E9, Canada • 519-966-4901

A CSW Industrials Company. RectorSeal, the logos and other trademarks are property of RectorSeal, LLC, its affiliates or its licensor's and are protected by copyright, trademark and other intellectual property laws, and may not be used without permission. RectorSeal reserves the right to change specifications without prior notice. ©2023 RectorSeal. All rights reserved. R50112-1223